

www.ipi-global.com



Industrial
Packaging
Innovations

economic, safe and easy to use

DV - Drum Valve

Fill Head



User Instructions

Connection



1. Fill Head with filling and vapour recovery hoses attached.



2. Align Fill Head pins with corresponding slots in Drum Valve.




3. Rotate Fill Head clockwise 1/3 turn until it stops.




4. Engage the Fill Head by pushing down on the handle.

The drum is now ready to fill.

Typical Fill Head vapour recovery system



Disconnection



- 1. Caution: Turn off pump first!**
Pull handle out and lift.



- 2.** Rotate Fill Head counter clockwise 1/3 turn until it stops.
Fill Head may now be removed.