

www.ipi-global.com



economic, safe and easy to use

DV - Drum Valve

Heavy Duty Coupler



User Instructions

Connection




1. Heavy Duty Coupler with extraction and vapour recovery hoses attached.



2. Align Heavy Duty Coupler pins with corresponding slots in drum valve.




3. Rotate Heavy Duty Coupler clockwise 1/3 turn until it stops.



4. Engage the coupler by pushing down on the handle.
The system is now ready to dispense.

Typical vapour recovery system using Heavy Duty Vapour Recovery Coupler.



Disconnection



1. Pull handle out and lift.
The system is now closed.



2. Rotate coupler counter clockwise
1/3 turn until it stops.
Coupler may now be removed.